

Channel Morphology - Stream Crossing Interactions

An Overview




Michael Love
Michael Love & Associates
mlove@h2odesigns.com
(707) 476-8938


Why Geomorphology for Fish Passage

1. Understand the Scale of the Barrier (local or related to watershed scale changes)
2. Base Design on Channel Morphology
3. Anticipate Channel Response to Project
4. Conduct Geomorphic Risk Assessments



Common Geomorphic Issues with Culverts





Definitions

Bankfull Discharge - For streams with adjustable banks, flow associated with water surface at edge of lowest depositional bank.


Average return period of 1.2 – 1.7 years (regional).


Video Guide to Field Identification of Bankfull Stage in Western US
http://www.stream.fs.fed.us/publications/bankfull_west.html


Active Channel - Line on the shore established by the annual fluctuations of water.

Physical Characteristics:

- Scour line along bank
- Destruction of terrestrial vegetation.








Channel Incision

Channel Incision – Lowering of the channel bed (a.k.a. degradation or downcutting).

Causes of Channel Incision:

- Channelization
 - Shortens channel length (increasing slope)
 - Reduces overbank storage, increasing peak flows.
 - Increases stream power (velocities and bed scour).




Example of Channelization
Little Browns Creek, Trinity County, CA

Original Disturbance:

- Channel moved during historical placer mining
- Downstream channel straightened for 5,000 feet for Highway 3

Result:




- Channel downstream of County culvert incised 9 feet.
- Unstable channel banks, numerous bank failures, continuing incising of channel bed, loss of riparian trees.



Channel Incision

Causes of Channel Incision (cont.):



- ❑ Deceased Sediment Supply
 - Gravel Mining
 - Dams

Channel Incision

Causes of Channel Incision (cont.):

- ❑ "Steam Cleaning" – Removal of Large Wood which controls the channel grade
- ❑ Increase in Peak Flows through changes in landscape
 - Urbanization ▪ Wildfire
 - Grazing ▪ Timber Harvesting

Head Cutting and Channel Incision

The diagram illustrates the process of head cutting. A dashed line represents the 'Flood Plain Elevation'. A solid line shows the 'Original Stream Grade' which has a 'Nick point' where it drops abruptly. A lower solid line shows the 'New Stream Grade' after incision. The vertical distance between the original and new grades at the nick point is labeled 'Height of Incision'.

Headward retreat of a Nick Point, an interruption in a stream's longitudinal profile.

Evolution of Channel Regrade

The diagram shows three stages of channel evolution:

- 1. Before Incision:** A cross-section showing a 'Terrace', 'Floodplain', and 'Channel'.
- 2. Regrade Incises:** The channel has deepened into an 'Incised Channel'. The 'Old Terrace' is now a 'New Terrace'. The channel banks are labeled as 'Oversteepened Banks'.
- 3. Floodplain Evolution:** The channel has further deepened into a 'New Channel'. The 'Old Terrace' is now a 'New Floodplain'. The channel bank remains 'Oversteepened Bank'.

Channelization - Case Example

Carmen Valley Watershed – Plumas NF


Lower Incised Channel with Active Head Cut

A head-cut has formed as the channel regrades, causing the bed to lower as it moves upstream

Channelization - Case Example

Carmen Valley Watershed – Plumas NF

Lower Incised Channel



Incised channel beginning to develop a new lower floodplain. The former wetland has dried with the lowering of the water table.

Impacts of Channel Incision

Degradation places a stream in great danger of dramatic change.

- Disconnection with flood plain.
- Lowered water table and loss of riparian vegetation.
- Oversteepened banks and bank failures.
- Large episodic and chronic releases of fine grain sediment.





Impacts of Channel Incision

- Degradation of fish habitat:
 - Redds highly susceptible to scour.
 - No escape from high velocities
 - Loss of pool habitat
 - Increased turbidity and sedimentation
 - Lower summer base flows, causing dry-up prematurely.
 - **Knickpoints (fish barriers)**




Incised channel upstream of culvert replacement







Other Channel Degradation Indicators

- Visible Nick Point or Head Cut**
- Lack of Sediment Deposition** – Erosion of channel bed down to bedrock or other resistant soil layers.
- Toe of Bank is Vertical** – lack of sediment layering at streambed-banks interface, exposed roots
- Lack of Pools** – Long reaches of riffle or run with no pools
- Cultural Features Exposed** – Perched culverts or exposed bridge footings, aprons, and pipelines





(List adapted from J. Castro, 2003)

Extent of Natural Regrade

<p>McCready Gulch</p>  <p>Upstream Structure Exposed Bedrock</p>	<p>Morrison Gulch</p>  <p>Perched Outlet</p>
<p>Upstream of perched culvert, prior to removal</p>	<p>Perched Outlet replaced by a culvert</p>

Rate of Natural Regrade

More mobile the bed material, more rapid the channel regrades

 <p>Boulder Channel</p>	 <p>Sand Bedded</p>
---	---


Considerations for Culvert Replacements

Downstream Channel has Incised

- Grade Control at Project Site**
 - Log or Boulder Weirs
 - Roughened Channels
 - Fishways, Baffles
- Uncontrolled Regrade (no grade control)**
 - Let it Rip!
- Restoration of Downstream Channel Profile**
 - Raise channel bed and reconnect/construct floodplain
 - Reestablish grade controlling features
 - Stabilize streambanks
 - Reestablish riparian vegetation

Channel Aggradation


Increased sediment loads combined with large flood can cause entire streams and rivers to aggrade.



Channel Aggradation and Culverts


Culvert replacements after flood events have added complexity and risk:

- Anticipating future regrade.
- Determining vertical placement of culvert invert or arch-footings.
- Providing enough flood capacity in aggraded state.



Crawford Creek near confluence with Klamath River

Culverts and Localized Aggradation




Undersized culvert frequently ponds water upstream

As water slows upstream of crossing, localized aggradation occurs

Impounded wetlands may form

Case Example
Upstream Aggradation


Groundhog Creek
Middle Fork RD, Willamette NF



Photos courtesy of Kim Johansson

Case Example
Upstream Aggradation

Groundhog Creek Middle Fork RD, Willamette NF




Looking Upstream

Photos courtesy of Kim Johansson

Conclusions

- Perched culverts often result from larger-scale channel incision, and not site-scale channel changes.
- Incision is not caused by culverts
- Potential consequences associated with removing a culvert nick-point requires careful consider.
- When replacing culverts after large floods, consider channel instability.
- Issues of upstream aggradation are usually at the site-scale.
- Design for anticipated variability in channel elevation over the life of project



Conclusions

Consider the scale of channel restoration and protection needed when beginning a culvert replacement project.